

Instruction Manual



50 memories time switches




Safety precautions

- The connection and installation of electrical devices may only be carried out by a qualified electrician.
- Interventions in and changes to the device result in the voiding of the warranty claim.
- Observe your national regulations and the respective safety provisions.
- Switch-off commands have priority over switch-on commands.




Assembly


MIL 72 D150




MIL 72A D150



MIL 72E D150




MIL 72 D250




Connection

MIL 72 D150
MIL 72A D150
MIL 72E D150
FMD 150




MIL 72 D250






Accessory


MIL 72 D150



Terminal cover
01.78.0004.6




Sealing glas - IP40
01.78.0021.6




Multi-terminal busbar, latch
01.78.0036.6

MIL 72E D150




Flush mounting base
01.79.0002.2

MIL 72 D250



Sealing glas

Sealing screw
16.10.0011.8



General information

- The middle communication line shows the selectable menu item. If confirmed with **OK**, this item is activated.
- Flashing texts or symbols require an entry.
- If no entries are made within the next 2 minutes, the clock reverts to Auto mode.

Function displays of the two left-hand buttons:

- △ scroll up in menu
- ▽ scroll down in menu
- ☒ Select/reject suggestion
- ✓ Select/accept suggestion
- + Press briefly = +1
Press and hold (approx. 2 sec) = +5
- Press briefly = -1
Press and hold (approx. 2 sec) = -5

Display

- A** Function displays of the two left-hand buttons
- B** Channel status displays
 — 1 = Channel 1 ON
 / 1 = Channel 1 OFF
 Channel 1 = C1, Channel 2 = C2
- C** 3 communication lines for time display, menu items, entry prompts etc.
- D** Day-of-week display
- E** Overview of daily switching program
- F** Display of summer/winter time
- G** Operating voltage (permanently lit dots)
Reserve power operation (dots flash)
- H** Function displays of the two right-hand buttons


Buttons

- I** Reset
The programs are retained in the case of a reset. The date and time must be set again. Press reset button with a blunt object (pen).
- J** Right-hand buttons
- K** Left-hand buttons with manual switch function in Automatic mode

Function displays of the two right-hand buttons:

- MENU** Exits the Automatic mode and enters the Programming mode
- ESC** Press briefly = one step back
Press and hold (approx. 2 sec) = return to Automatic mode
- OK** Make selection and apply
- EDT** Change request in Read mode
- NO** Do not execute command
- YES** Execute command
- DEL** Delete


Initial start-up - selection of menu language




Info

In the delivered state the time switch is in the Auto mode with a preset time, date and the menu language English.

Prog.




View, edit program



Info

- The program steps can be scrolled through with \blacktriangledown \blacktriangle .
- The respective program can be edited by pressing **EDT**. The procedure is the same as when creating a new program.


Delete all programs



Info

- It is possible to delete all programs with **YES**.
- By pressing **NO**, individual programs can be deleted.

Delete individual programs




Info

When deleting individual programs, the corresponding program steps are deleted (e.g. P01 ON and P02 OFF).




Set date and time



Info


The date and time are preset at the factory.

Set AM/PM (12-hour-) or 24-hour display





Switchover for summer/winter time



Info

The following settings are possible:

AUTO

Factory presetting of the published calendar dates. This is automatically recalculated for each year.

NO

No switchover

CALIBRAT

Programming. The start date of the summer time and winter time must be entered for this purpose. The factory presetting is overwritten. The programmed summer/winter time is automatically recalculated for each year. The changeover takes place on the same specified day of the week in the same week of each month.

Example

03/21 Start summer time
10/31 Start winter time



Operating mode



Info

Left-hand button = Channel 1

Right-hand button = Channel 2 (only with
2-channel version)

Press 1 x = FIX ON = continuous ON

Press 2 x = FIX OFF = continuous OFF

Press 3 x = return to Auto mode

FIX ON:

FIX OFF:

AUTO: (no display) programmed switching times