



OWNERS INSTRUCTION MANUAL

This instruction sheet applies to the following PROGRAMMABLE WALL SWITCH SECURITY Timer Models:

MODEL: EJ341 (Single Pole): For incandescent lights controlled from a single wall switch. For fluorescent light control see IMPORTANT NOTES.

MODEL: EJ343 (Three-Way): Same as above for lights controlled from two locations.

Manufactured under one or more of the following patents: 4,274,045, 4,270,058, 4,344,000, 4,349,748, 4,349,7488, 4,360,739, 4,379,245, 4,439,688 and other patents pending.

IMPORTANT NOTES

Your PROGRAMMABLE WALL SWITCH SECURITY Timer is designed to operate standard incandescent light bulbs or thermally protected Class P) ballast fluorescent lighting ONLY. It requires a minimum lamp load totalling 40 watts and can handle a maximum combination totalling 500 watts.

It is NOT TO BE USED to operate MERCURY VAPOR LIGHTS, APPLIANCES, RADIOS, TVS, STEREOS, etc.

Separate dimmers and photoelectric switches cannot be used in combination with your timer. We recommend that your Timer not be used with "PAR" or "R" type outdoor flood lamps or lamps larger than 150 watts, since currents generated during lamp burn-out could damage the timer.

Your Timer generates radio energy and may in rare cases cause radio or television interference. Possible solutions include: readjusting the receiver's antenna, plugging the receiver into a different AC outlet or moving the receiver itself.

CONTROLS AND INDICATORS

MODEL EJ341 & J343 (See Fig. 1)

CONTROL LEVER. In OFF-CLEAR position all power is removed from timer and controlled light(s); this also clears the memory. In ON position, timer is in operation and is ready for programming.

ALL MODELS

PUSHBUTTON/TIME DIAL Press once to turn lights on or off manually. Press twice quickly to switch from AUTOMATIC to MANUAL mode; press twice quickly again to switch back to AUTOMATIC mode. Rotate to set AUTOMATIC operation times or for review.

RED INDICATOR LIGHT. Indicates status of timer. When light is,



1. FLASHING: Timer memory has been cleared and timer is ready to be programmed.

NOTE: Also PULSES momentarily when dial is rotated during RAPID PROGRAMMING or REVIEW.

2. OFF: Control lever is in OFF position or timer is in one of 3 modes: MANUAL operation; BEING PROGRAMMED, or in REVIEW.

3. ON STEADY: Timer is programmed and in AUTOMATIC Mode.

AM/PM INDICATOR. AM or PM. Reference for programming and review.



INSTALLATION


Your Timer replaces a standard toggle switch. It fits into a wall box easily and uses the same wires as the switch you took out. If you can install a wall switch, you can install the Timer. The only tools needed to install your timer are a flat blade screwdriver and a phillips head screwdriver. Carefully pull off the pushbutton time dial and remove the cover assembly from timer before proceeding with the installation.

1. **TURN POWER OFF** to the wall switch by removing fuse or breaking the circuit.

2. **REMOVE SWITCHPLATE AND EXISTING SWITCH.**

3. **MODEL EJ341 TIMER** (See Fig. 2) Disconnect wires from old switch and connect them to the Timer. Use wire nuts provided. If old switch has ground wire (normally

connected to green hex head screw) fasten it securely to metal box or to timer metal bracket.



Trim house bare wire to 7/16"; twist wire nut on both wires until it "locks" securely.

FIG. 2 Wiring Model EJ341





FIG. 3 Wiring Model EJ343

- 3A. MODEL EJ343 (See Fig. 3) 3 way timer package contains the timer for either wall location and a short "jumper" wire for the other location. Identify and remove wire (usually black) attached to "common" terminal of old switch. This terminal normally has a different color screw or may be identified by markings on switch body. Connect to black lead of timer using wire nut. Remove the other two wires and connect one to the red and the other to the blue timer wire.
4. **MOUNT TIMER** into wall box, being careful not to cut wires on box edges, using flat head screws supplied.
5. **ALIGN SWITCH PLATE** with timer bracket by placing upper screw hole of plate over red indicator light.
6. **INSTALL CONTROL PANEL** by inserting clear plastic lens in upper screw hole of plate. (Not applicable for decorator style switch plates). Install fillister dome head screw in bottom hole & black flat head screw in hole above center shaft & metal tab. Tighten screws snug, but **DO NOT OVER-TIGHTEN**. If either "AM or PM" is not centered in the window rotate the gear wheel just below the window with your finger.
7. **INSTALL PUSHBUTTON TIME DIAL** with flat side of control shaft aligned with flat in time dial. Press on just far enough to engage shaft making sure the dial spring encircles both the metal tab and the shaft. Rotate dial until "6" is at the top then press dial fully onto shaft. **INSTALLATION IS COMPLETE FOR MODEL EJ341.**
8. **INSTALL JUMPER WIRE** at second 3 way location for MODEL EJ343 (See Figure 4 and 5).



MOVE JUMPER WIRE TO OTHER TERMINAL IF THIS SWITCH DOES NOT TURN LIGHT ON
FIG. 4 Model EJ343 Installing jumper wire at switch.




Fig. 5 Model EJ343 3-way wiring diagram.

NOTE: For new construction or to replace either a dimmer switch or a 3-way switch without screw terminals, a single pole switch can be used at the remote location.

BE CERTAIN POWER IS OFF.

Screw Terminal Switches: Remove plate and screws from second 3-way switch, pull switch from wall box. Identify "common" terminal and loosen screw just enough to install one end of the jumper under the screw head. Retighten screw. Loosen screw at either of the two other terminals and install other end of jumper wire. Retighten screw.

Reinstall switch and turn power back on. Turn timer on by moving control lever to on position. Try operating light using second (remote 3-way) switch. Rewire the jumper to go from the "common" terminal to the other terminal. Reinstall switch and turn power back on. Both the remote switch and the timer should now be able to control the light.

Dimmer, illuminated or back wire pressure terminal switches: Replace with a single pole non-dimmer switch. Identify "common" wire; attach it together with one of the other wires, under either screw terminal.

Remaining wire should be attached under the other screw terminal.

Turn power back on. Move control lever to ON (or BRIGHT). Operate remote 3-way switch, light should turn on and off from this switch. If not, **TURN POWER OFF** and move "common" wire and reconnect under the other terminal, together with the single wire already in place. Turn power back on and repeat test procedures.

PROGRAMMING YOUR ELECTRONIC IN-WALL TIMER

Programming can be accomplished in 2 ways

RAPID PROGRAMMING. Enables you to make desired time settings in just minutes. Achieved as follows:

1. Move control lever to OFF-CLEAR for at least 5 seconds; red indicator light will go off, and all previous time settings will be cleared from memory.
2. Move lever to ON. RED INDICATOR will start FLASHING.
3. Check a clock; then rotate time dial clockwise at least one click, stopping at the half hour nearest to present time (note AM or PM indication). **NOTE:** When rotating time dial, do NOT accidentally PRESS at the same time.
4. Press pushbutton once to enter present time. RED INDICATOR will go OFF, present time has now been recorded.
5. Rotate time dial clockwise to desired ON time; RED light will PULSE momentarily with each click.
6. Press pushbutton to enter ON time; controlled light(s) will turn on.
7. Rotate dial to desired OFF time.
8. Press pushbutton to enter OFF time; controlled light(s) will now be off.
9. Repeat Steps 5-8 for each addition ON/OFF period.
10. Continue to rotate time dial for at least 24 hours from the first ON time to complete this program, at which time the RED INDICATOR light will come ON and stay ON, indicating timer is in AUTOMATIC mode. **NOTE: Dial does not rotate automatically after setting to indicate time of day.**

24-HOUR SELF PROGRAMMING. Accomplished by use of the Timer as a standard light switch over a 24-hour period.

1. Move control lever to OFF-CLEAR position for at least 5 seconds; RED INDICATOR light will go OFF, and previous time settings will be cleared from memory.
2. Move lever to ON. RED INDICATOR light will start FLASHING.
3. Turn light(s) on and off as you normally would during this 24 hour period. When you turn lights ON the first time, RED INDICATOR light will go OFF and remain OFF. However, if you should turn light(s) off in less than 30 minutes from the ON time, RED INDICATOR will resume FLASHING. Reason: Each on/off period must be at least 30 minutes.

At the end of the first 24 hour period, your Timer will be fully programmed, red indicator will stay ON and timer will automatically repeat the lighting pattern you entered during the 24 hours.

PROGRAM REVIEW enables you to determine the ON/OFF settings in your Timer memory. Proceed as follows:

1. Timer must be in AUTOMATIC mode (RED INDICATOR light ON).
2. Rotate time dial clockwise at least one click, stopping at nearest half hour to present time (note AM or PM indication).
3. Press pushbutton once to start review (RED INDICATOR will go OFF).
4. Rotate time dial clockwise slowly observing time on dial when controlled light(s) go ON AND off (RED indicator will PULSE with each click).
5. Press pushbutton once to end review (RED INDICATOR will go ON and stay ON. Timer is in AUTOMATIC mode.)

NOTE

Reviewing does not in any way altering the program. Once a program is stored it can be changed only by switching to OFF-CLEAR, which clears the entire memory.

TROUBLE SHOOTING GUIDE

TROUBLESHOOTING GUIDE FOR TIMER WALL MODELS EJ341, EJ343

SYMPTOM:	SOLUTION:
1. Timer cannot be programmed using rapid method.	a. Was timer programmed according to instructions? b. Is control lever in ON position? c. Is red indicator light flashing at beginning of programming sequence? d. Was present time entered before programming desired ON and OFF times? e. Is pushbutton/time dial being depressed fully?
2. Timer does not turn lights ON or OFF automatically, as programmed.	a. Was timer programmed according to instructions? b. Is timer unintentionally in manual mode (red indicator light off)? c. Be sure light bulbs are tightly in their sockets and are not burned out. d. Check wiring for loose connections.
3. Timer does not turn light(s) ON or OFF using pushbutton.	a. See solution No. 2c and 2d. b. Check fuse or circuit breaker.
4. Timer is warm to the touch.	a. Some warmth is normal. Be sure light bulb wattage does not exceed ratings.
5. Controlled light flickers or goes to half brightness.	a. Recheck wiring diagrams and instructions.
MODEL EJ343 ONLY:	
6. Controlled light cannot be turned ON or OFF from the remote switch.	a. Check for proper jumper installation b. Make sure control lever is not in OFF position. c. Is the remote switch the proper type?

SPECIAL NOTES

SWITCHING FROM AUTOMATIC TO MANUAL OPERATION MODE

If you wish to switch temporarily to MANUAL mode without disturbing the stored program, press the pushbutton quickly twice. The red indicator light will go off, you Timer is now in the MANUAL mode. Your controlled light(s) can be operated manually. To return to AUTOMATIC OPERATION mode, press the pushbutton quickly twice again; the red light will go on, indicating the timer is again in the AUTOMATIC mode.


YOUR Timer Is ALWAYS A LIGHT SWITCH

With the Timer in AUTOMATIC mode, you can use it as a conventional ON/OFF light switch just by pressing the pushbutton once each time you wish to turn the lights on or off. This overriding of the stored program will not disturb the next automatic operation; your light(s) still turn on or off at the next programmed setting.

BURNED -OUT BULBS

If a bulb controlled by your Timer should burn out, the red indicator light will go off, alerting you that you have a burned-out bulb, and that your timer will not operate automatically. To restore normal operations, move control lever to OFF-CLEAR position and replace light bulb. Now move lever back to ON position for EJ341 and EJ343 models, then re-program timer. MODEL EJ343

This Timer may fail to operate if the remote switch is located 30 feet or more from the timer. For such applications we recommend you use model SS5C.



Your New Electronic Timer can now be used to replace a Decorator (Rocker) style switch using any standard single or multi-gang switch plate.

Use with either toggle style or decorator style switch plate.

SPECIFICATIONS

- **POWER SUPPLY REQUIREMENTS:** Operates in series with 120 VAC, 60 Hz. incandescent lighting loads.
- **LOAD CAPACITY,** Incandescent or thermally protected (Class P) ballast Only: MODELS EJ341, EJ343 40-500 watts.

NOTE: Derate to 400 watts maximum when two or more Timers are installed in same wall box. For fluorescent control see caution note under IMPORTANT NOTES on page 1.

- **MINIMUM ON OR OFF PERIOD:** 30 minutes.
- **REPEAT CYCLE:** 24 hours.
- **DAILY OPERATIONS:** Up to 48 (24 ON periods and 24 OFF periods).
- **VARIABILITY:** ON and OFF times automatically vary at least 7 minutes from the time programmed and at least 15 minutes from the previous day.
- **POWER FAILURE MEMORY PROTECTION:** In case of power failure, the Timers memory will be retained for a minimum of 15 minutes, depending upon conditions at time of power failure.

WARRANTY

If within one (1) year from the date of purchase, this product fails due to a defect in material or workmanship, Intermatic Incorporated will repair or replace it free of charge.

The warranty does not apply to: (a) damage caused by accident, abuse, mishandling, dropping, (b) units which have been subject to unauthorized repair, opened, taken apart; (c) units not used in accordance with directions; (d) damages exceeding the cost of the product. Some states do not allow a limitation of damages, so the foregoing limitation may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

This warranty service is available by either (a) returning the product to the dealer from whom the unit was purchased or (b) mailing postage prepaid to the nearest authorized service station listed below. Please be sure to wrap the product securely when mailing to avoid shipping damage. This warranty is made by Intermatic Incorporated, Intermatic Plaza, Spring Grove, Illinois 60081-9698.

SERVICE CENTER / SERVICE CENTRE / CENTRE DE SERVICE

INTERMATIC INCORPORATED, INTERMATIC PLAZA
SPRING GROVE, IL 60081-9698 (815) 675-7000
<http://www.intermatic.com>

158EJ8623

PRINTED IN U.S.A.