



TE02DHB/TE22DHB


Indoor 1-Outlet Digital Timer

Instruction Manual & Warranty

Before using your timer, please read instructions carefully.

FEATURES

- 20 programmable ON/OFF settings per week
- 12 hour AM/PM & 24 hour display
- Programmable in 1 minute interval
- Random ON/OFF Feature (2-30 minutes of programmed time)
- Manual Override Button: select temporary for one program period, or permanent override.



KEY FUNCTIONS

- SET: set time and confirm the program setting
- [+]/[-]: increase or decrease digit in setting
- FUNCTION: change output state to ON/OFF and set program
- RESET: initialize or reset unit

CLOCK TIME SETTING

1. Press SET button for 3 seconds. Week digits will flash on display.
2. Using [+] or [-] buttons set the correct week. Week day will increase or decrease continuously if [+] or [-] buttons are depressed for more than 1 second.
3. Press SET button again to set Hour. Hour digits will flash on display.
4. Using [+] or [-] buttons to set correct hours. Hour will increase or decrease continuously if [+] or [-] buttons are depressed for more than 1 second.
5. Press SET button again to set Minutes. Minute digits will flash on display.
6. Using [+] or [-] buttons set the correct Minutes. Minute will increase or decrease continuously if [+] or [-] buttons are depressed for more than 1 second.
7. Press [-] button for 3 seconds to choose 12 hour AM/PM or 24 hour display.
8. Press [+] button for 3 seconds to set Daylight Saving Time, 'DST' will appear on display. Press again to cancel.

PROGRAMMING OF SWITCHING TIMES (ON/OFF)

1. Press FUNCTION button 5 times until 'PROG 1 ON' appears on display and flashes.
2. Press the SET button, using [+] or [-] buttons to set the Day(s) of first program.
3. Press the SET button, using [+] or [-] buttons to set the hour of the first On program.
4. Press the SET button, using [+] or [-] buttons to set the minutes of the first ON program.
5. Press the SET button, "1 on" will flash. Press [+]. "1 off" will now flash.
6. Repeat steps 2-4 above to set the corresponding OFF time for Program 1.
- Note:** Pressing and holding [+] or [-] buttons will rapidly increase or decrease time settings.
- Note:** Pressing [+] or [-] buttons simultaneously cancels current setting.
7. Repeat steps 2-5 to set ON/OFF times for additional programs (up to 20 total programs per week).
8. After all programs have been set, press FUNCTION button to return to "current time" screen.
9. If programming is interrupted for more than 10 seconds while setting timer, until will automatically exist setting mode. Preset time will be preserved.

Note 1: Programming of switching times (ON/OFF) will not work properly if 'PROG ON' overlaps with 'PROG OFF'.

RANDOM ON/OFF SECURITY FEATURE

Press FUNCTION button until 'RND' digits flash on display, press SET button to enter Random Mode. 'RND' will appear on display. Programmed ON/OFF time will randomly fluctuate in a range of 2-30 minutes. Repeat the operation above to cancel 'RND' function

COUNT DOWN ON/OFF SETTING

1. Press FUNCTION button 6 times until 'CTD' and 'ON' digits flash on display.
 2. Press SET button, 'ON' digits will flash on display, use [+] or [-] to set hours.
 3. Press SET button, use [+] or [-] to set minutes.
 4. Press SET button, use [+] or [-] to set seconds.
 5. Press SET to initiate countdown sequence. Device will turn on, screen will indicate AUTO ON, and remaining time will be shown on screen. When countdown reaches 0:00:00, device will turn off.
- Press FUNCTION button to check current time

Note: Countdown function overrides all others. Exit Countdown mode before using other functions.

MANUAL OVERRIDE SETTING

Use Function button to toggle settings.

On: Device is On, will not be subject to programmed settings.

Off: Device is Off, will not be subject to programmed settings.

Auto On: Device is currently On, will run settings as programmed.

Auto Off: Device is currently Off, will run settings as programmed.

RESET BUTTON

Press RESET button. Timer will resume in default status.

IMPORTANT SAFETY PRECAUTIONS

- Use indoors only.
- Keep device out of the reach of children.
- Do not plug this timer into another timer switch.
- Do not plug any device performing mechanical movement directly into timer.
- Do not insert needles or any other metal objects into mains outlet.
- Avoid moisture, extreme temperatures, shock and vibration.
- Do not open timer. Repairs must be performed by authorized service personnel only.
- To clean casing and display use a soft cloth. Do not use chemical or scouring agents. Do not submerge in water.

RATINGS

120VAC, 60Hz
5A, Resistive or General P
240W Tungsten
Back-up Battery: Recharge

CLASSE

120 Vca 60 Hz
5 A Résistif ou Utilisation
240 W Tungstène
Pile de secours : recharge

CLASIFICACIONES

120 VAC, 60 Hz
5 A, Resistivo o Uso Gener
240 W Tungsteno
Bateria de respaldo: Recar



Westek TE22DHB timer

Limited One Year Warranty

AmerTac™ warrants this product to be free from defects in material and workmanship for a period of one year from the date of purchase. AmerTac's obligations are limited to repairing or replacing any defective unit and are effective only if such units are returned within one year of the purchase date to AmerTac, 250 Boulder Drive, Breinigsville, PA 18031. Warranty void if damage is due to misuse or improper installation. In no circumstance will AmerTac be liable for consequential or incidental damages relating in any way to this product.

Garantía limitada de un año

AmerTac™ garantiza que este producto está libre de defectos de material y mano de obra por un periodo de un año a partir de la fecha de compra. Las obligaciones de AmerTac se limitan a reparar o cambiar la unidad defectuosa y son efectivas sólo si se devuelve en un lapso de un año a partir de la fecha de compra a AmerTac, 250 Boulder Drive, Breinigsville, PA 18031. La garantía no será válida si el daño es causado por mal uso o instalación inadecuada. En ningún caso AmerTac será responsable por daños consecuentes o incidentales relacionados en cualquier forma con este producto.

Garantie limitée d'un an

AmerTac™ garantit ce produit contre tout défaut de matériaux et de main d'œuvre pendant une période de un (1) an à partir de la date d'achat. Les obligations d'AmerTac se limitent à la réparation ou au remplacement de tout article défectueux et s'appliquent seulement si l'article est retourné dans l'année de la date d'achat à AmerTac, 250 Boulder Drive, Breinigsville, PA 18031. AmerTac ne peut en aucun cas être tenue responsable pour des dommages consécutifs ou accessoires liés de quelque manière que ce soit à ce produit.

Questions?, ¿Preguntas? 201.934.3224

©2010 AmerTac™
Saddle River Executive Centre,
One Route 17 South, Saddle River, NJ 07458
www.amertac.com
Made in China
Hecho en China
Fabriqué en Chine



110-0061-A