

Possible instruction manual for Tesco 7 day electronic Mains timer



Plug timer into outlet for 1 hour to charge internal battery.
Unplug timer when ready to set programming.
Press reset button to clear memory.

Timer might have different formats: for example Clock format to set current time, and PGM format to set program.

Try setting formats with different combination of buttons.
For example hold down manual button and press set button.
Or press manual button and then push up and down buttons.
Or simply press manual button several times until correct format displays.



To set current time: Press Set button and Hours start blinking.
Press up-down buttons until current hour displays. Note AM-PM for correct hour setting.
Press Set button and Minutes start blinking.
Press up and down buttons until current minutes display.
Press Set button and Days of week start blinking. For example MO for Monday.
Press up and down buttons until current day displays.
Press set button to confirm setting.

To program timer: Each program requires ON time and then OFF time, with Hour, Minute and Day for each.
Press Set button and Minutes start blinking for ON time.
Press up-down buttons until ON hour displays. Note AM-PM. This is the Hour you want timer to turn ON.
Press Set button and Minutes start blinking.
Press up and down buttons until ON minutes display.
Press Set button and Days of week start blinking.
Press up and down buttons until ON day displays. Timer possibly offers blocks of days, for example MO TU WE TH FR will display for weekdays. SA and SU for weekend.

Press Set button and Minutes start blinking for OFF time.
Press up-down buttons until OFF hour displays. Note AM-PM. This is the Hour you want timer to turn OFF.
Press Set button and Minutes start blinking.
Press up and down buttons until OFF minutes display.
Press Set button and Days of week start blinking.
Press up and down buttons until OFF day displays.

Timer may have more than one program available. Each program will have ON time and OFF time.
Set ON and OFF times for each program, making sure there are no time conflicts that will cause timer not to operate as expected.
To use random mode, timer programs have to be spaced at least ½ hour apart from each other.

Select mode:

Timer appears to have at least 2 different modes: Auto and Random show on display.
Press manual button to select Auto mode. Select this mode to operate programmed functions.
You might have to press manual button and then push up and down buttons to arrive at Auto.
Or simply press manual button several times until Auto displays.
Press manual button to select RDM or random mode: random mode turns lights on and off at random times that are within ½ hour of programmed times. Random mode gives appearance that somebody is home.