



Digital 2-Outlet timer #0155671 #TH06WHBL

---

## Instruction manual and Warranty

**Features:** two 3-prong grounded outlets  
7-day programming, each day can be different  
Large digital display  
Random programming – residence appear occupied  
Just plug in to charge internal battery.  
Battery back up for programming  
Manual override

### Setting procedure

- [+] or [-] Increase or Decrease time setting
- RDN: Press Random ON/OFF setting to activate random delay for start or finish of ON periods.
- RST: To reset, press reset key with pointed object, like paper clip or pencil
- CTD: Countdown indicates time left before appliance is turned off.
- Manual: Manual override

If programming is interrupted for more than 10 seconds while setting timer, unit will automatically revert to default mode. Preset time will be preserved.

### Setting Time: clock time is set before programming

1. If display does not appear, plug timer into outlet and charge battery for 1 hour.
2. Remove unit from wall to program
3. Press and hold Time key. Select 12 or 24 hour display.
4. Press and hold Set key.
5. Press [+] or [-] to select current Day
6. Press set key again until hour flashes
7. Press [+] or [-] to select current Hour
8. Press set key again until minute flashes
9. Press [+] or [-] to select current Minute
10. Press set key. Time is now set.

### Programming ON/OFF settings (maximum 20 events)

1. To begin, press + key: Display will show PROG 1 ON
  2. Press Set key. Use [+] or [-] to select choice of Day(s)
- Day options are:

- All week: MO TU WE TH FR SA SU
- Individual days of week
- Weekdays: MO TU WE TH FR
- Weekends only: SA SU
- TH FR SA
- MO TU WE
- TU TH SA
- MO WE FR

3. Press Set key again to select Hour using [+] or [-]
4. Press Set key again to select Minute using [+] or [-]
5. Event 1 ON is set, next set Event 1 OFF
6. Press Set key again And then press [+] key  
Display will show PROG 1 OFF
7. Repeat steps 3 through 5 to set Day(s) and time for Event 1 OFF
8. To set Event 2 through Event 20, press [+] key and repeat steps.
9. When programming is finished, press Time key and current time will display

### Deleting Programs

1. Press [+] key. Use [+] or [-] keys to select Event ON/OFF
2. Press Set key to select Event. Press Manual key to delete.
3. When finishes, press Time key for current time display

### Count Down ON/OFF setting

1. Press [-] key. Display will show CTD programming
2. Press Set key. Use [+] or [-] to select hours
3. Press Set key. Use [+] or [-] to select minutes
4. Press Set key. Use [+] or [-] to select seconds
5. Press CTL key to begin countdown., press CTL to end countdown
6. Press Time key for current time display

### Random Switching

Use this feature to turn lamps and appliances on-off in random pattern. Useful for vacation, so home appears occupied. Press RND. Display shows RND indicating that random programming is now activated.  
Press RND to deactivate and return to programming.

### Manual Override

Manual override is used to switch on and off.  
Press Manual repeatedly and display scrolls through ON, AUTO ON, OFF, AUTO OFF. When AUTO is displayed, timer will run programs. When AUTO is not displayed, timer will not run programs until override key is pressed and AUTO displays.

### Reset Key

Press RST key. Timer will resume in default status, all programs and setting will be lost.

### Ratings:

20 programs per week; 15 amp; 1500 watt general purpose; 5 amp, 600 watt tungsten (incandescent); 120V 60 Hz.

Limited One Year Warranty

[www.ameritac.com](http://www.ameritac.com)

1-201-934-3224