



0331645
TE08WHBL

RATINGS

120V / 15A / 1800W
14/3 AWG SJT Vinyl Power Cord

POWER SAVING STRIP TIMER
8 Outlet Power Strip With Digital Timer - 7 Day Programmable
Function with 4 Outlets Based On Timer
and 4 Outlets Always On-Switched



TIMER OPERATING INSTRUCTIONS

GETTING STARTED

Install a 1.5 volt "AG-13" mercury battery in battery compartment on back of timer and then close the cover. All of the display shows for 3 seconds, then the display will read as shown in Fig. 1.

Fig. 1



SETTING THE CURRENT TIME

While holding the CLK (CLOCK) button down, press the DAY, HR (HOUR) and MIN (MINUTE) buttons to set the day of the week, hour and minutes respectively.

PROGRAMMING EVENTS

1. Press the PROG button once. The display reads
 - 1 ON MO TU WE TH FR SA SU --:-- , if it has not been set.
 - 1 ON and previous setting, if it has already set.

The number 1 indicates that you are now programming timer #1.
2. Press the DAY button repeatedly. The display shows the day on which you want the timer to turn ON.
The day options include:
 - All days of the week (MO TU WE TH FR SA SU)
 - Any single day of the week (MO TU WE TH FR SA SU)
 - Weekdays only (MO TU WE TH FR)
 - Weekends only (SA SU)
3. Press the HR (HOUR) and MIN (MINUTE) buttons to select the time of day when you want the timer to turn ON.
4. Press the PROG button once again. The display reads
 - 1 OFF MO TU WE TH FR SA SU --:-- , if it has not been set.
 - 1 OFF and previous setting, if it has already set.
5. Repeat the procedure in steps 2 and 3 to select the day and time when you want the timer to turn OFF.
6. Repeat the procedures in steps 1 to 5 to select the time and day when you want the timer to turn ON and OFF for the other six events.
7. When programming is complete, press the CLK (CLOCK) button to return to the current time display.



REVIEWING AND CLEARING YOUR PROGRAMS

1. Press the PROG button repeatedly to check the ON and OFF setting for each event.
2. While holding the MODE button down, press the PROG button to clear the setting. Push clock button to return to main.

ACTIVATING YOUR PROGRAMS

1. Press the MODE button until the AUTO indicator is displayed. The timer will operate automatically as programmed.
2. Press the MODE button until the RDM (RANDOM) indicator is displayed. The timer will operate randomly as programmed.

Random is a feature that will randomize your current settings either + or - 30 minutes giving your home a lived in appearance to deter intruders.

MANUAL OVERRIDE

1. Press the MODE button until the ON indicator is displayed. The output of the timer will turn and remain on until the mode is changed again.
2. Press the MODE button until the OFF indicator is displayed. The output of the timer will turn off and remain off until the mode is changed again.

OPERATING THE TIMER

1. Plug the power strip into an outlet.
2. Plug the appliances to be controlled by the timer into un-used timed outlets on the power strip.
3. Turn the switch on the strip timer to the "on" position.
4. Make sure that appliances are turned on.