

How to program

Westek TE06WHB 7-day programmable

Timer has rechargeable battery.

Plug timer into outlet for 1 hour to charge battery and LCD will display.

Unplug timer to program

Make schedule of programming times before starting.

Timer will not perform correctly with conflicting on-off schedules

Up to 8 ON/OFF programs per day >> program 1 program 2 ... through program 8

Choice of individual days, or blocks of days

Set time of day:

Press TIME button

MO – TU – WE – TH – FR – SA – SU will display

Press +- button to select current day of week

Press Set to confirm

Hour will be flashing on display

Press +- button to select current hour

Press Set to confirm

Minutes will be flashing on display

Press +- button to select current minutes

Press Set to confirm

Program 1 ON Hour will be flashing (ready to start programming On time hour for Program 1)

Press +- button to select Hour you want program 1 to turn ON

Press Set to confirm

Program 1 ON Minutes will be flashing (ready to start programming On time minutes for Program 1)

Press +- button to select Hour you want program 1 to turn ON

Press Set to confirm

Program 1 ON Day(s) of week will be flashing

Press +- button to select Day or block of days you want program 1 to turn ON

Press Set to confirm

Repeat same steps to set Program 1 Off time

Program 1 is ready.

Continue setting more programs

Press manual button until auto displays

To access Random or Countdown mode, press manual button.

