

INDOOR TABLETOP
TIMER
DIGITAL



Model 59417 Indoor Digital Tabletop Timer

Instructions

Setting the current time

1. Press the SET button on the Timer.
2. Press the (+) button to increase the minutes and hours or the (-) to decrease the minutes and hours (AM is represented with hours 1-12 and PM is represented with hours 13-24).

Programming the Timer

1. Press the SET button for program 1 to be ON (A1 will appear on the left side of the screen).
2. Press the (+) button to increase the minutes and hours or the (-) button to decrease the minutes and hours until the desired ON time is displayed (AM is represented with hours 1-12 and PM is represented with hours 13-24).
3. Press the SET button for program 1 to be OFF.
4. Press the (+) button to increase the minutes and hours or the (-) button to decrease the minutes and hours until the desired OFF time is displayed (AM is represented with hours 1-12 and PM is represented with hours 13-24).
5. Repeat steps 1-4 for setting program 2.
6. When finished press the SET button until current time is displayed.

To clear a program, push the (+) and (-) buttons at the same time while in the desired program.

Resetting the Timer

1. Press the RESET button to clear all programs and restart the programming steps.
- To override the ON or OFF settings, press the ON/OFF button. The override setting will change at the next timed event.
 - Display will return to the current time after 10 seconds without any action during the setting process.
 - Hold the SET button for over 3 seconds, the display will return to the current time.

FOR INDOOR USE ONLY.

DO NOT EXCEED RATED CAPACITY:

- 5' SPT Power Supply Cord
- 125V / 60 Hz
- 10A / 1250W Resistive (general purpose)
- 8A / 1000W Tungsten (lighting)
- 8.3A Standard Ballast Load
- 500VA Electronic Ballast
- 1/3 HP

KEY	
SET	Move through the clock and programs
+	Move minutes forward
-	Move minutes back
ON/OFF	To override the ON & OFF settings for each program
RESET	Clear all programs

