

MODEL: 22T904A

BREAKER HOLD-DOWN KIT

For compliance with National Electrical Code Article 384-16 (g), this HOLD-DOWN bracket must be installed, if a breaker is used as a BACK-FED DEVICE.

1. Install the plug-in type main breaker in position next to LINE 1 lug.
2. Secure breaker in place by installing bracket to base with screw furnished as shown.

