

**Intermatic HB65R timer**

Outdoor timer

6' cord, 15A, 1875 Amp

1. Power up, perform self-test  
If error, EE flashes for 3 seconds, if normal 88 flashes 3 seconds, then display shows C
2. Push Time to set current time 1-24 hours, push MODE when done display shows p.
3. Push TIME to set start time, push MODE when done, then E displays
4. Push TIME to set end time, push MODE when done, then current time displays
5. MODE button can now be used to toggle between ON and current time

C stands for current time

P stands for start ON time

E stands for end OFF time

