

If Wiring Combination 120- and 240-Volt Loads:

- For combination 120- and 240-Volt loads, change the factory default setting of the Source Voltage Selection Jumper on the back of the Three-Circuit Clock mechanism (P1353ME) from its factory default setting to 120 Volts.
- For more information, see *Identifying Connections and Selecting Proper Input Voltage* on page 26.




Figure 3-6