

# TimeIt

## Daily Digital Timer

2-Wire Polarized Outlet and Plug  
120VAC 60Hz, 5A 600W Resistive Load  
Customer Service: 1.800.730.3707

### READ ALL INSTRUCTIONS - IMPORTANT!

Before using the timer plug it in for 10 - 15 minutes; then press the reset button

### SET CURRENT TIME:


- 1 Press and hold the **"TIME"** button, then press the **"HOUR"** button to set the current hour.
- 2 Press and hold the **"TIME"** button, then press the **"MINUTE"** button to set the current minute.

### SET PROGRAM:

- 1 Press and hold the **"PROG"** button 1 second to enter the program setting; you will see **"PROG 1 ON"** on the display.
- 2 Press the **"HOUR"** button to set the **"PROG 1 ON"** hour.
- 3 Press the **"MINUTE"** button to set the **"PROG 1 ON"** minute.
- 4 Press the **"PROG"** button 1 second and repeat step 2 and 3 to set **"PROG 1 OFF"**.
- 5 After setting the **"PROG 1 OFF"** press the **"TIME"** button once to return to the current time

You can set up to 6 different ON and OFF times for your timer. To do so, just repeat step 2 to 4 for **"PROG 2 ON"**, **"PROG 2 OFF"**, **"PROG 3 ON"** etc...

28441\_00441 Daily Digital Timer



### MANUAL OVERRIDE:

Pressing the **"MODE"** button when the current time is being displayed will allow you to set the status of the timer:

- If **"ON"** is to the left side of the display the timer will be active until **"MODE"** is pressed.
- If **"OFF"** is to the left side of the display the timer will not activate until **"MODE"** is pressed.
- If no icon is to the left side of the display the timer will run on the program setting until **"MODE"** is pressed.

### NOTES:

- 1 The unit you are plugging into the timer has to be on.
- 2 Make sure AM and PM are correct on the current time and in the program settings.

**SAVE THESE INSTRUCTIONS!**