

# TimeIt

## Weekly Digital Timer

2-Wire Polarized Outlet and Plug  
Rated: 120VAC 60Hz, 5A 600W Resistive Load  
Customer Service: 1.800.730.3707

### SET CURRENT TIME:

- ① Press and hold the **"TIME"** button 3 seconds to set the current day; you will see the day flash.
- ② Press the **"+"** or **"-"** to set the current day.
- ③ Press the **"+"** or **"-"** to set the current hour.
- ④ Press the **"TIME"** button once more to set the current minute; you will see the minute flash.
- ⑤ Press the **"+"** or **"-"** to set the current minute.


### SET PROGRAM:

- ① Press and hold the **"PROG"** button 3 seconds to enter the program setting; You will see all the days of the week flashing on the top and **"PROG 1 ON"** to the left of the display.
- ② Press the **"+"** or **"-"** to set the **"PROG 1 ON"** days of the week that you want the timer to function.
- ③ Press the **"TIME"** button once, then press the **"+"** or **"-"** to set the **"PROG 1 ON"** hour.
- ④ Press the **"TIME"** button once more, then press the **"+"** or **"-"** to set the **"PROG 1 ON"** minute.
- ⑤ Press the **"PROG"** button once and repeat step 2 to 5 to set **"PROG 1 OFF"**.
- ⑥ After setting the **"PROG 1 OFF"** press the **"MODE"** button once to return to the current time.

You can set up to 8 different ON and OFF times for your timer. To do so just repeat step 2 to 5 for **"PROG 2 ON"**, **"PROG 2 OFF"**, **"PROG 3 ON"** etc...

### READ ALL INSTRUCTIONS - IMPORTANT!

Before using the timer plug it in for 10 - 15 minutes; then press the reset button



28443\_00443 Weekly Digital Timer

### MANUAL OVERRIDE:

Pressing the **"MODE"** button when the current time is being displayed will allow you to set the status of the timer:

- If **"ON"** is to the left side of the display the timer will be active until **"MODE"** is pressed.
- If **"OFF"** is to the left side of the display the timer will not activate until **"MODE"** is pressed.
- If **"AUTO"** is to the left side of the display the timer will run on the program setting until **"MODE"** is pressed.

### SET VACATION SECURITY:

Pressing the **"TIME"** and **"PROG"** buttons simultaneously will activate security mode. If **"SEC"** is to the right side of the display the timer will turn on randomly during different parts of the day. Simply press **"TIME"** and **"PROG"** simultaneously to disable **"SEC"**.

### NOTES:

- ① The unit you are plugging into the timer has to be on.
- ② Make sure AM and PM are correct on the current time and in the program settings.

### SAVE THESE INSTRUCTIONS!