

# TimeIt

## Extreme Temperature Outdoor Timer

3-Wire Grounded Outlet and Plug

Rated: 125V/15A/1875W/60Hz (8A/1000WTungsten)

Customer Service: 1.800.730.3707

### INSTRUCTIONS:


Follow the steps below to set the current time and the timer ON and OFF times.

- 1 Plug the timer into a power outlet - "C" will flash on the Digital LED.
- 2 Set Current Time: push the "TIME/MODE" button to set the current hour. The dot at the bottom right of the Digital LED will appear to indicate PM hours.

**NOTE:** The timer indicates hours only. Therefore for accurate timer function, it is a good idea to set the current time close to the beginning of the hour (12:00, 1:00, 2:00, etc).

- 3 Set Timer ON time: push the "ON" button to quit and save the current time setting. "P" will flash on the Digital LED. Push the "ON" button repeatedly to set the desired ON time.
- 4 Set Timer OFF time: push the "OFF" button to quit and save the ON time setting. "E" will flash on the Digital LED. Push the "OFF" button repeatedly to set the desired OFF time.
- 5 Quit and save initial setting: push the "TIME/MODE" button to quit and save the initial setting. The Digital LED will display the current time and start the normal operation.

**NOTE:** The initial setting must follow the above procedure, otherwise the unit will not start the normal operation and will wait to finish programming. To start over, unplug the timer, wait 30 seconds, and plug the timer back in.



### E-Z SETUP

- TIME MODE** Set CURRENT Time
- ON** Set ON Time
- OFF** Set OFF Time

### NOTES:

The unit you are plugging into the timer must be turned on.

### WARNING:

When used outdoors this timer must be plugged into a GFCI protected outlet to prevent shock hazard. Let the switch hang downward so moisture doesn't accumulate in the outlet. Install cord and unit above ground level with the receptacle in downward minimum 1.5m above ground. Suitable for damp locations. Not for water immersion or for use were directly exposed to water. Store indoors when not in use.

DO NOT splice, repair or modify. Unplug when not in use. Fully insert plug. DO NOT use damaged remote sets. Inspect periodically. Use within the electrical rating as the specification. DO NOT plug more than a total 1,000 watts in this unit. If watts are not marked on appliance, multiply ampere rating (on nameplate) by 125 to determine equivalent watts. Add determined watts for each plugged-in appliance or lamp (sum of watts on bulbs) to find total watts being used. Operating temperature range -30C (-22F) to 45C (113F).

### LIMITATIONS OF TIMING DEVICES:

Timing devices require power to function properly. If AC power to the timer is cut off, a light or other device plugged into the timer will not work.

### SAVE THESE INSTRUCTIONS!