

<http://waterheatertimer.org/Intermatic-trippers-and-parts.html#trippers>

Additional-Intermatic-trippers

**156T1960A** - Timer Tripper, For Timer Number 2E025, Adjustable

**156T1961A** - Timer Tripper, For Timer Number 1A219, 1A220, 1A573, 1A850, 2A208, 2A209, 2E021 thru 2E053, 2E258, 2E259, 2E351, 2E352 thru 2E354, 4A214, 4E023 thru 4E026

**156T2978A** - Timer Tripper, For Timer Number 2A206, 2A512, 2E026, 2E130, 2E131, 2E214, 2E355, Thru 2E357, 2E389, 2E408, 6X757, 6X761, 6X762, Package 12

**156EB1945A** for E1020, E1022, EB11, EB11R & WH21

**156T1948A** Trippers One Set (ON/OFF/ON Cutout) for T170, P171, T1400 & T1800 Series

**156T1949A** Tripper Variable (10 to 60 minute) for Model T185

**156T1950A** Trippers (12 ON or OFF) for T1900, T2000, C8800, R8800 & T8800 Series

**156T1978A** Trippers (1 ON / 1 OFF) for T100, T170, T7000, & WH40 (Same as 156T3492A)

**156T2548A** Trippers 7 Sets (ON / OFF) for T7400 & T7800 Series

**156T3230A** Trippers (1 ON / 1 OFF / 1 On Cutout) for WH Series