

<http://waterheatertimer.org/GE-timers-and-manuals.html>

INSTRUCTIONS:

Plug timer into GFCI protected outlet (total wattage should not exceed 1000 watts). Choose from the following functions by rotating the selector dial:

(OFF) POWER OFF

(ON) POWER ON

(2, 4, 6 Or 8 Hrs) ON at dusk, **OFF (2), (4), (6) or (8)** hours later

(DUSK-DAWN) ON at dusk, **OFF** at dawn

Not for permanent installation. Do not install or use this product for more than a 90 day period per year. When used outdoors, plug only into a GFCI protected receptacle. Receptacle should be mounted in an approved "weatherproof while in use" type outlet box.

IINSTRUCTIONS :

Branchez la minuterie sur une prise protégée de type disjoncteur de fuite de terre (le nombre de watts total ne devrait pas dépasser 1000 watts). Choisissez l'une des fonctions suivantes en tournant le cadran de sélection :

(OFF) HORS TENSION

(ON) SOUS TENSION

(2, 4, 6 Or 8 Hrs) (2, 4, 6 ou 8 h) sous tension au crépuscule, mise hors tension **2, 4, 6 ou 8** heures plus tard

(DUSK-DAWN) (crépuscule-aube) Sous tension au crépuscule, hors tension à l'aube

Ne l'utilisez pas pour une installation permanente. N'installez pas ou n'utilisez pas ce produit pendant une période dépassant plus de 90 jours par année. Si la minuterie est utilisée à l'extérieur, branchez-la uniquement sur une prise protégée de type disjoncteur de fuite de terre. La prise doit être montée dans un boîtier de prise de type « à l'épreuve des intempéries lorsqu'elle est utilisée ».

15254-1