

How to program Timex TX12874X

24 hour plug-in digital timer

Clear timer of previous programming by pushing HOUR and MINUTE buttons at same time.

To set current time, hold TIME button down and push HOUR.
Then hold TIME button down and push MINUTE.

To set ON time for lights to go on: hold the ON button down and push HOUR until it gets to the hour you want it on (repeat steps to set minute).

To set OFF time for light to go off, hold the OFF button down while you set the hour and minute.

Confirm programming: Press Time button once to put timer into Auto ON-OFF. Use ON and OFF buttons to temporarily override timer until next set point when timer resumes scheduled programming.

Timer repeats same program each day.



<http://waterheatertimer.org/Woods-timers-and-manuals.html#Timex>