



Legrand 03740 vertical analog timer instruction manual

230V 50-60Hz Rated max 16 amps



Protect timer with fuse.

Wire timer as shown above.

Use 2-pole or 3-pole contactor for loads over 16 amp, and for 3-phase

Set current time by rotating dial

Move dial until current time aligns with triangle mark



Set ON-OFF times by moving segments horizontally

Manually rotate timer dial to watch how load turns ON-OFF

Move override lever to each position and rotate dial again.

This will show how to set ON-OFF times

More DIN rail timers

[Hagar timers and manuals](#)

[Intermatic Din rail timers](#)

[Misc Din rail timers](#)

[Tork Din rail timers](#)

Legrand 03700 digital timer

<http://waterheatertimer.org/How-to-wire-Legrand-03700-timer.html>

<http://waterheatertimer.org/Din-rail-timers-and-manuals.html>

Installation on DIN rail

