

Possible manual for TM series digital timers from Hunshine

Set current time

Press and hold Clock button

Press Week button to select current day

Press Minute and Hour buttons to select current hour and minute

Program timer.

Press Time button until 1 and ON display

This is Program1 ON

Press Week button to select day(s) for program1 ON

Press Minute and Hour buttons to select when program1 turns ON.

Press Time button until 1 and OFF display

This is Program1 OFF

Press Week button to select day(s) for program1 OFF

Press Minute and Hour buttons to select when program1 turns OFF.

Press Time button until 2 and ON display

This is Program2 ON

Press Week button to select day(s) for program2 ON

Press Minute and Hour buttons to select when program2 turns ON.

Press Time button until 2 and OFF display

This is Program2 OFF

Press Week button to select day(s) for program2 OFF

Press Minute and Hour buttons to select when program2 turns OFF.

Continue to set more programs.

When in programming mode, press RES/RCL to change programs.

When programming is complete, press ON/AUTO/OFF button

Select Auto for programming to operate

Press Random button and timer will turn on-and-off at more random times to simulate that someone is home. Use this feature when leaving for evening or on vacation.