

## Westek SLC6CFL timer instructions



Westek timer is similar to other 1-button timers:

Press the TIMER button to select how many hours you want the timer to operate after nightfall: 2 hours, 5 hours, 8 hours , or until dawn.

Light will turn ON automatically at dusk, and turn OFF 2-5-8 hours later, or at Dawn depending on timer selection choice.

The timer also has Random function, which probably means timer turns ON at dusk, but turns OFF at random times until dawn to give appearance that home is occupied.

How to install:

Screw timer into outdoor light socket.

Apply bit of WD40 to threads so timer is easy to remove at later date. Apply WD40 to bulb too.

Screw light bulb into timer socket. Make sure bulb is good.

Timer works with tungsten (incandescent) or CFL bulbs up to 100 watts.

If outdoor lighting has several light bulbs on same switch, then install Westek timer in each socket, and each outdoor bulb can be up to 100 watts.

60 watt bulbs will save money over using 100 watt bulbs.

Turn light switch ON. Switch must be ON for timer to work.

Press TIMER button on side of timer to cycle through choices.

The button sequence repeats same choices in a cycle.

Open following link to see other 1 button timers:

<http://waterheatertimer.org/Woods-timers-and-manuals.html#N1502>

### **Note:**

-Photo eye should face darkest area possible, and timer can reset itself if exposed to other lights, or car lights.

-Do not exceed 100 watt rating.

-Timer has 5 year warranty, so save purchase receipt.