

OUTDOOR MECHANICAL

**TIMER**

WITH PHOTOELECTRIC EYE



## Model 2001 and 49647 Outdoor Mechanical Timer

### Instructions

- Off** – Always OFF
- On** – Always ON
- Dusk-Dawn** – Lights turn ON automatically at dusk and OFF at dawn\*
- 2,4,6,8 hours** – Lights turn ON automatically at dusk and OFF 2, 4, 6, 8 hours later\*

\*Cycle repeats every 24 hours.

DO NOT SUBMERGE IN WATER.

DO NOT EXCEED RATED CAPACITY.

Use a 3 conductor, GFCI-protected outlet.

This device must be mounted in a vertical position with the receptacle facing downwards and the receptacle not reaching the ground level.

6" 18/3 SJTW cord  
125V / 60 Hz  
8.3A / 1000W Tungsten (lighting)



Coleman Cable, Inc.  
Waukegan, IL 60085  
© 2008 Coleman Cable, Inc.  
Printed in China