



Thank you for purchasing our Woods Model TM1720 – Electro Mechanical Timer.

Before using your timer, please read the following instructions carefully.

FEATURES

- Automatically turns lights ON/OFF
- Choice of operation mode – Dusk to Dawn, 1-2-3-4-5-6-7-8 hrs or manual ON/OFF
- Ideal for Christmas lights.

INSTALLATION

Mount the timer on wall near grounded electrical outlet with photo sensor facing outwards. (Note: To ensure proper operation of the automatic function, ensure that the photocell sensor is shielded from all nighttime light sources, such as floodlights, etc). The head of the nail or screw must extend at least 3/16” (0.5cm) from wall (nails or screws are not included). Hang the timer by placing the slot on back of unit over the nail or screw. Plug the timer’s power cord into outlet.

INSTRUCTIONS

Rotate the dial on the timer to one of the following settings :

OFF = Lights always OFF

ON = Lights always ON

1, 2, 3, 4, 5, 6, 7, 8 =Automatically turns lights ON at Dusk and OFF after 1, 2, 3, 4, 5, 6, 7, or 8 hours

DUSK-DAWN = Automatically turns lights ON at Dusk and OFF at Dawn

SPECIFICATIONS

120V AC/60Hz

8.3A/1000W Resistive

8.3A/1000W Tungsten

DO NOT SUBMERGE

RAIN TIGHT

If further assistance is required please call:

1-800-561-4321

416-267-4614 (Toronto and surrounding regions)

Monday to Friday from 8:30AM to 5:00PM Eastern Standard Time

Woods Industries (Canada) Inc.

375 Kennedy Rd., Toronto, Ontario, Canada, M1K 2A3

www.woods.com