

INDOOR MECHANICAL
TIMER

WITH NEVER-LOSE PINS



Model 59201 Indoor Mechanical Timer

Instructions

1. To set the current time, rotate the dial until the time lines up with the TIME NOW arrow.
2. To program the timer, push the pins outward for the periods of time you want the timer to be ON and push the pins in toward the center dial for the periods of time you want the timer to be OFF.
3. Set the switch on the side of the timer to TIMER. Plug device in to the timer and turn the device on. Plug timer into outlet.

FOR INDOOR USE ONLY.

DO NOT EXCEED RATED CAPACITY:

125V / 60 Hz
15A / 1875W Resistive (general purpose)
10A / 1250W Tungsten (lighting)
1/3 HP



Coleman Cable, Inc.
Waukegan, IL 60085
© 2008 Coleman Cable, Inc.
Printed in China