

INDOOR/OUTDOOR

# LIGHT CONTROL

WITH PHOTOCELL

## Model 59409 Indoor/Outdoor Light Control with Photocell

### Instructions

1. Carefully disconnect the power supply.
2. The body of the light control must be located in a weatherproof enclosure. Remove the nut from the face of the photocell and set aside.
3. Connect the black power line wire (hot line) to the black wire on the light control. Connect the black wires from the light fixture to the red wire of the control. Connect the white wire from the light fixture and white wire of the control to the white power line wire (neutral).
4. To reinstall the wall plate, insert the nipple through the hole in the wall plate; reattach the nut on the photocell to create a watertight seal. Install the two wall plate screws.
5. Turn on power supply. **When dark**, the photocell will turn on the bulb and the cycle begins.

For use in dry locations only  
Not for use with dimmers or bug zappers

120Vac / 60Hz  
500W Tungsten  
850VA Ballast



Coleman Cable, Inc.  
Waukegan, IL 60085  
© 2010 Coleman Cable, Inc.  
Printed in China