

N1507 timer instructions

N1507 timer instructions

PROGRAMMING THE TIMER:

1. Install the battery.
2. You don't need to plug the timer in to program it.

SETTING THE CLOCK:

3. While holding the CLOCK button down, press the DAY, HOUR and MIN buttons to set the current day and time.

PROGRAMMING AN EVENT:

4. Press the PROG button once. The display will read: TIMER 1 ON --:--. The numeral 1 indicates that you are now programming Timer #1.
5. Press the DAY button repeatedly. The display shows the day (or combination of days) on which you want the timer to turn ON. The day options include:
 - a. Any single day of the week (MO, TU, etc.)
 - b. Weekdays only (MO TU WE TH FR)
 - c. Weekends only (SA SU)
 - d. All days of the week (MO TU WE TH FR SA SU)
6. Continue by pressing the HOUR and MIN buttons to select the time of day when you want a timer to turn on.
7. Press the PROG button once again. The display will read TIMER 1 OFF --:--.
8. Repeat the procedures in steps 5 and 6 to enter the day (or combination of days) etc. and the time when you want a timer to turn off.
9. When programming is complete, press the CLOCK button to return to the time display. Your programs are now stored in memory.

TO REVIEW YOUR PROGRAMS:

10. Press the PROG button. The display will show they ON time and day(s) for event number 1. Press the PROG button again to display the OFF time and date.

Each time you press the PROG button, the display will advance to the next event and instruction. Make sure unused timers display blank times (Blank time is --:-- , not 00:00).

11. To return to time display, press that CLOCK button.

ACTIVATING PROGRAMS:

12. After pressing the CLOCK button, press the MODE button until TIMER is displayed. The unit will now operate automatically as programmed.

MANUAL OVERRIDE:

Press the MODE button until ON or OFF is displayed. You will not lose your program(s) as they are stored in memory. To cancel manual override, press MODE button until TIMER is displayed.