

INDOOR LIGHTING

TIMER

DIGITAL



Model 59203EV Indoor 7-Day Digital Timer

Instructions

Charge the Battery

Plug timer into wall outlet for a few minutes to charge internal battery.
NOTE: If it would be easier, you can now unplug the timer to set it.

Clear the Memory

Press the RESET button with a tooth pick to erase any previous settings.

Select AM/PM Format

1. Press and hold the CLOCK button for about 5 seconds until display shows 24H or 12H, then release.
2. Press the HOUR button as many times as necessary to change display to "12H".
3. Press the CLOCK button to restore the normal clock display. The letters "AM" should show in upper left corner of the display.

Set Time of Day

1. Press and hold the CLOCK button.
2. At the same time, press the HOUR and MINUTE button as many times as necessary to advance the display to the correct time.
3. Hold down the DAYS button until the display shows the correct day.

Set ON/OFF Times

1. Press the PROGRAM button once to display the first ON/OFF setting – "1 ON --:--".
2. Press the MINUTE and HOUR buttons as necessary to set the ON time you want.
3. Press the DAYS button as necessary to choose the day or group of days you want for the time setting.
4. Press the PROGRAM button again to display the second ON/OFF setting – "1 OFF --:--".
5. Repeat the procedure to create the OFF setting.
6. Repeat Steps 1 thru 5 for additional ON/OFF settings.
7. Press the CLOCK button to exit from PROGRAM mode.

FOR INDOOR USE ONLY.

DO NOT EXCEED RATED CAPACITY:

125V / 60 Hz

8.3A / 1000W Resistive (general purpose)

4.8A / 600W Tungsten (lighting)

Things to know about ON/OFF timers:

- Repeatedly pressing the PROGRAM button cycles through the possible 20 ON/OFF pairs: 2 ON, 2 OFF, 3 ON, 3 OFF, etc.
- The display panel automatically returns to time of day if you don't press any buttons for 15 seconds.
- If you are interrupted before completing a setting, simply press the PROGRAM button until you reach the setting where you left off.

Review ON/OFF Settings

It is important to review all 20 settings, even if you only used a few, to make sure there are not extra, unintended settings.

1. Press the PROGRAM button (hold down to scroll) until the display cycles through all 20 ON/OFF pairs.
2. Stop on any setting you want to remove or change.

To Revise a Setting

1. Press the PROGRAM button (hold down to scroll) until the display shows the setting you want.
2. Press the HOUR, MINUTE and WEEK buttons as necessary to revise the displayed ON/OFF time and day(s).

To Remove or Restore a Setting

1. Press the PROGRAM button (hold down to scroll) until the display shows the setting you want to remove or restore.
2. Press the RST/RCL button.
 - If removing, the display will replace the setting with dashes.
 - If restoring, the display will show the previous setting.

To Operate the Timer

1. After setting the timer, plug it in and connect the device to be controlled.
2. Press the ON/AUTO/OFF button as necessary to display:
 - ON-the timer remains ON and ignores your settings.
 - OFF-the timer remains OFF and ignores your settings.
 - AUTO-the timer follows your settings.



Coleman Cable, Inc.
Waukegan, IL 60085
© 2008 Coleman Cable, Inc.
Printed in China