

How to program Westek TE06WHB

Timer has rechargeable battery.

Plug timer into outlet for 1 hour to charge battery and LCD will display.

Unplug timer to program

Make schedule of programming times before starting.

Timer will not perform correctly with conflicting on-off schedules

Up to 8 ON/OFF programs per day >> program 1 program 2 ... through program 8

Choice of individual days, or blocks of days

Set time of day:

Hold down CLOCK button

Press DAY button to choose current day MO - TU

Press HOUR button to set current hour

Press MIN button to set current minute

Release Clock button and current time is set

Program preview

>For each ON time, you set DAY HOUR and MIN

>For each OFF time, you set DAY HOUR MIN

> So Program1 has ON and OFF settings that each require DAY HOUR and MINUTE

> Program 2, 3 , 4 etc also have ON and OFF settings that require DAY HOUR and MINUTE

Choose individual days or blocks of days > for example TH FR SA is one block; MO WE FR is another block ,, there are 9 possible blocks of days... in addition to choosing individual days.

> Make sure days or block of days match for both ON and OFF times.

Look at display prompts while programming

For example, look for number 1 or 2 or 3 etc located on left of display

1 is Program 1; 2 is program 2; 3 is program 3.

Look for ON that indicates you are setting ON time for program 1 or program 2

Look for OFF that indicates you are setting OFF time for program 1 or program 2

Program timer

Press PROG once and see '1' and 'ON'

This is program 1 ON

You are ready to set ON time for program 1

Press DAY to choose block of day for program 1

Press HOUR to choose ON hour for program 1

Press MIN to choose ON minute for program 1

Press PROG button once to validate ON time for program 1

Keep pressing PROG button until display shows '1' and 'OFF' in tiny letters. This is program 1 OFF.

Press DAY to select block of days >> if you chose ON for TH FRI SAT, you probably want OFF on same block of days

Press Hour to choose OFF hour for program 1

Press MIN to choose OFF minute for program 1

Press PROG button once to validate OFF time for program 1



Keep pressing PROG until display shows '2' and 'ON.'
This is program 2 ON.

You are ready to set ON time for program 2
Repeat previous steps to set program 2 - 8

Press PROG button to advance to program 3 through program 8
Press PROG button once to validate ON-OFF times for each program

Press ON/Off button to exit programming, and timer is ready

Manual override

Press manual button to select following options:

Each option will show on display

Permanent ON, select Manual ON

Permanent OFF, select OFF

Select Auto OFF to override program until next program setting

Select AUTO for programs to work

Countdown feature

Press CLOCK and PROG simultaneously

Set countdown using HOURS and MIN buttons

Max 9 hours and 59 minutes.

Press MANUAL button to start countdown.

Lamp will turn ON until end of countdown.

Random

Press DAY and HOUR simultaneously, and R will display

Turn off random, press DAY and HOUR again

Other features

Daylight savings time: Press HOUR & MIN buttons

simultaneously and clock springs forward 1 hour ... press again and clock falls back 1 hour

Look for S in display to see if timer set for S summertime

Press reset to clear all programming