

INDOOR

# TIMER


WITH NEVER-LOSE PINS



## Model 22575, 48174US 8 Outlet Power Strip with Indoor Mechanical Timer

### Instructions

#### To Set The Timer

1. Turn the inner dial and align the timer symbol  with the arrowhead.
2. Set your desired **ON/OFF** time.

**NOTE: PM hours are highlighted in gray.**

**RULE:** Pulling up the gray tabs will turn appliances attached to the power strip **OFF**.  
Pushing down the gray tabs will turn appliances attached to the power strip **ON**.

- 2.1 Pull up all gray tabs around the module using your fingertips. When the tabs are all up, it indicates that the timer setting is in the **OFF** position. There are a total of 96 tabs in the module and each tab is equivalent to 15 minutes. 96 tabs represent 24 hours in a day.
- 2.2 Next, using the tip of a pen, gently push down each tab at the specific time/s of the day you want your appliance **ON**.
- 2.3 You may program as many desired **ON/OFF** times for your appliance as you want.

#### To Set Current Time

Rotate the timer dial clockwise slowly until the current time is set against the arrowhead. Please note that each of the 24 numbers in the dial represents the time of day.

#### To Install the Power Strip

1. Plug the power strip into a 125V outlet. The timer will not start until the power strip is plugged into your outlet.
2. Plug your appliance/s into any of the four (4) timer-controlled outlets. (Please note that the other 4 outlets to the right side of the power strip are controlled by the red switch located above the timer dial.)
3. Turn the red switch on.

#### To Override the Timer

Override the Timer by turning the inner dial and aligning the arrowhead with the symbol, **"O"** for the timer always **OFF** or the symbol, **"I"** for the timer always **ON**.



Coleman Cable, Inc.  
Waukegan, IL 60085  
© 2008 Coleman Cable, Inc.  
Printed in China